

Verification of Square Frame

Step

1. Take a tape measure and measure from the top left corner to the bottom right corner.
Record this dimension
2. Take a tape measure and measure from the top right corner to the bottom left corner.
Record this dimension
3. Note: measure from outside metal to outside metal
 - a. NOTE: if one side of the frame has a flange and the other side does not, measure from the interior of the frame corner
4. Dimensions should be within 1/16" of each other
 - a. If frame is not square, it will need to be reinstalled

