

How to determine the net opening of a walk-in.

1. When measuring, always measure the actual opening from the panel to panel.

**DO NOT MEASURE THE FRAMES OR DOORS**

2. Each dimension should be measure in at least 3 points. This will ensure that you are calculating the “smallest” net opening which will ensure that the frames will fit properly in the opening.
3. Measurement should be to the 1/16”

